


Step 14: Take out one counterweight peg. Mount the counterweight hanger on the end of the arm, making sure to use the center hole in the end of the arm.



Step 15: Hang the counterweights

Take out the last counterweight peg. Slip the weights onto the counterweight hanger and slide the counterweight pin into the hole in the bottom of the counterweight hanger to keep the weights in place:



Step 16: Make the sling

Take the pouch material out of the hardware bag. Poke four holes in each end of the pouch material:

