

MODULE 5: Soldering and PCB

BU SUMMER CHALLENGE
Electrical Engineering: Smart Lighting Project

Beste Oztop
PhD Student
Boston University
boztop@bu.edu


Overview

- Soldering Overview
- Soldering Lab - VLC PCBs

VLC Transceiver


- Components

- 2 - Sockets
- 1 – LM741 Op Amp
- 1 – LM393 Comparator
- 1 – Photodiode
- 1 – White LED
- 1 – HB LED
- 4 – Header Pins
- 7 – Resistors



Soldering Overview


- PCB: Printed Circuit Board
- Thru-hole: Components with leads that go through the circuit board and get soldered on the other side.
- Surface-mount: Components that are soldered on the same surface on which it is mounted.
- Track/trace: The “wires” connecting components.
- Pad: Exposed points where components are soldered.
- Silkscreen: Print text on PCB



Side View of a Through-Hole Component


Thru-Hole vs. Surface Mount

- Surface Mount Advantages
 - Smaller size and more compact layout
 - Components can be placed on both sides of the board
- Thru-Hole Advantages
 - Much easier to solder by hand
 - Easier to rework




Schematics vs. Layout

- Schematics are a symbolic representation of the circuit
- Layout indicates the physical arrangement on the PCB



Schematic



Layout

About Soldering




- Process of joining metal items together by melting a filler metal (solder) and contacting the items to be joined.
- Requirements:
 - Heat source (Soldering Iron)
 - Low melting point metal (Solder)
 - Flux (Prevents oxidation)
- Temperature
 - Typically set around 700°F
 - DO NOT TOUCH THE IRON!!
 - Note: Wires can also get very hot



Temperature Controlled Solder Station




Lab Instructions

- Insert leads through the holes in the PCB
- Turn board over and bend leads outward
- Clean iron tip on a damp sponge
- Tin the iron tip by applying solder, then wipe again



Lab Instructions

- Apply the iron such that it contacts the pad and lead
- Apply solder to the joint, NOT the iron
 - The heated metal of the pad and lead should melt the solder
- Use wire cutters to clip the excess lead.
 - Be cautious when clipping the lead!
- Have a TA inspect the board for shorts



Desoldering

- Copper Solder Wick/Braid
 - For removing excess solder
 - Braided copper mesh “pulls” solder off the board



- De-Solder Vacuum
 - Uses a vacuum action to pull solder from the board

Teams

- Team 1:
- Team 2:
- Team 3:
- Team 4:
- Team 5:
- Team 6:
- Team 7:
- Team 8:

Experiment

- Soldering Lab
- When you finish:
 - Return to the classroom
 - Work on Module 6 Activity I (Photodiode circuit)

Think – Pair – Share

WHAT?
did you
LEARN
today

An illustration of an open book with a magnifying glass resting on it, symbolizing learning and discovery.